



**Mustang
Quarter Window Closeouts
05-09 - CDC #112040
10-13 - CDC# 112041**

Note: Read installation instructions before installation. For best results Closeouts should be installed at 70°F or warmer. If necessary, warm the area with a hair drier or heat gun.

Component Check List:

| <u>Quantity/Description</u> | <u>Part #</u> | <u>CDC</u> | <u>Installer</u> |
|-----------------------------|---------------|--------------------------|--------------------------|
| 1 - Driver Side Closeout | 116042 | <input type="checkbox"/> | <input type="checkbox"/> |
| 1 - Pass. Side Closeout | 116043 | <input type="checkbox"/> | <input type="checkbox"/> |
| 2 - Alcohol Prep | 950006 | <input type="checkbox"/> | <input type="checkbox"/> |
| 1 - Instructions | | <input type="checkbox"/> | <input type="checkbox"/> |

Installation Instructions

1. Test fit parts to determine Driver and Passenger sides.
2. Clean inside of rear quarter windows with provided Alcohol Prep.
3. Peel all red backing from 3M Acrylic Foam Tape. (One side at a time)
4. Place Closeout against glass and press firmly.
5. Repeat for opposite of car.

Thank you for choosing Classic Design Concepts for your restyling needs. If you have any questions or concerns regarding installation please contact Tech@classicdesignconcepts.com or call 866-624-7997.