



2005-2013 Mustang Windscreen Installation Instructions CDC #: 0511-7011-01

Note: Read installation instructions before starting.



Component List:

- Windscreen
- Attachment Straps

Tools Needed:

- T-10 Torx[®] Bit

IMPORTANT NOTICE:

Windscreen Mesh material is a light duty material and will NOT support the weight of any object that is rested on it, while either installed on the vehicle or while being stowed in its storage bag. To maintain quality control, each screen is inspected prior to packaging and shipping. Any damage to the screen as a result of objects resting or falling onto the material WILL NOT be covered under CDC's warranty program.

1. Place Windscreen on the trim panels:



2. Securing the Windscreen to vehicle:

- A) Clip Attachment Straps into Windscreen leads
- B) Place the Windscreen Retainer Strap BEHIND the Seatbelt strap and secure the metal clip under the bottom edge of the Quarter Trim Panel. Disengage the Velcro of Retainer Strap and pull down on the Strap cinching the Windscreen down to the tops of quarter trim panels.



Note:

The Windscreen must be cinched down tight to prevent Screen from sliding against the Light Bar.

3. Positioning of the Windscreen:

Important!

Proper adjustment of Windscreen is necessary to prevent contact between Frame and Light Bar. If contact is made, there is a risk of damage to Light Bar vinyl (i.e. rub marks, shining, tare)

- A) Lift the upright section so that there is approximately a 1/2" gap between the Windscreen Frame and the Light Bar.



- B) There is a small T-10 Torx Head Setscrew at the hinge on each end. Adjust this setscrew to limit the forward travel of windscreen to maintain the 1/2" gap.



Thank you for choosing Classic Design Concepts for your restyling needs. If you have any questions or concerns regarding installation please contact Tech@classicdesignconcepts.com or call 866-624-7997.